# Running Engine Stand





# **Throttle Assembly Instruction Manual**

#### **Important Notes for Assembly:**

- This manual is for the Throttle add-on of the Running Engine Stand assembly.
   If you have not yet started with the Main Assembly instructions, start there before returning here.
- Use care when handling parts. There may be sharp edges and holes on components. Using thick protective gloves is recommended during the assembly process.
- Each bolt and nut should have the appropriately sized washer placed between the fastener and the frame.

#### **Required Tools:**

- Ratchet
- 7/16" Wrench
- 7/16" Socket
- 9/16" Wrench
- 9/16" Socket

# If you are experiencing problems upon installation— DO NOT RETURN THIS PRODUCT!


Most installation problems can be easily solved.

First contact technical support at:


Service@mechman.com

1 (888) MECHMAN or 865-522-6166

## **Included Components:**



#### **Included Hardware:**




### **Assembly Instructions:**

#### **Step 1:** Attaching the Throttle Bracket to the Assembly

#### **Required Components:**

- 1x Throttle Bracket
- Note: This step uses hardware from Step 7 of the Main Assembly instructions and should be completed simultaneously. If these steps are already complete, remove the necessary hardware and reinstall with the added bracket in place.
- Use the fasteners from Step 7 of the Main Assembly instructions to attach the Throttle Bracket to the Assembly.



## **Assembly Instructions:**

#### **Step 2:** Attaching the Throttle to the Assembly

Required Components: Required Hardware:

- 1x Throttle 2x 1/4"-20 x 1.25" Hex Bolt
- 2x 1/4"-20 Nylock Nut
- 4x 1/4" Flat Washer
- Use the 1/4"-20 x 1.25" Hex Bolts to attach the Throttle to the Throttle Mount Bracket.

